

Instructions for the cot

1. Take the frame of the cot out of the cupboard in the master bedroom



2. Place the frame on the left bed in the 2nd bedroom

3. Slide the frame into the 4 pins that are attached to the wall



4. Turn the 2 wooden blocks/stoppers downwards to lock the bed

